


The [control web-page](#) program is designed for customers who do not have an ability to build ControlOR control program.


The [control web-page](#) program is implemented in both MainAVR32 and Streaming board's Cavium. In other words, some pages are in MainAVR32 and others are in Streaming board.

It looks like one program. But, it is not.




That's why Control OR uses two different IP address. It is due to avr32's resource problem.

1. ControlOR's Ethernet port
  - 1) Main Ethernet port
    - Connect a LAN cable to the Main Ethernet port and power on the Control OR. Press "Display" button for 3 seconds in order to access Factory menu settings. Navigate through the menu you will find Network IP setting option then select that option you will see Main & Stream IP address etc.
  - 2) Stream Ethernet port
    - Connect another LAN cable to the Stream Ethernet port.
  - 3) Type in the Main IP address in your web browser then you will see the below login page. Default password is the same as the user name.
2. [Control web-page](#) w/ streaming and w/o streaming





Right page is in the streaming board.



Main
Video (1) | Video (2) | System

Small

Medium

Large

LU

RU

LB

RB

Size

Position

Contrast

Brightness

Temperature

Red

Green

Blue

Gamma

+ 50

+ 50

+ 0

+ 50

+ 50

+ 50

+ 0

CVBS1

CVBS2

YC1

YC2

RGBS

DSUB

DVI1

DVI2

SDI1

SDI2

Still

Blank

Main
Video (1) | Video (2) | Stream | System

Small

Medium

Large

LU

RU

LB

RB

Size

Position

Contrast

Brightness

Temperature

Red

Green

Blue

Gamma

+ 50

+ 50

+ 0

+ 50

+ 50

+ 50

+ 0

CVBS1

CVBS2

SV1

SV2

DSUB

RGB

DVI1

DVI2

SDI1

SDI2

Still

Blank

Right page is in the streaming board.  
Streaming access ID and password is  
given in this page.

System login ID and password can be changed  
in this page.

Main
Video (1) | Video (2) | Stream | System

Rate Control

Audio Control

FrameRate

GOP

Delay

SUBMIT

ON

OFF

clone

60

100

Network Configuration

DHCP

IP address

Subnet mask

Gateway

DNS Server

SUBMIT

ENABLE

DISABLE

192.168.11.135

255.255.254.0

168.126.63.1

SystemControl

Default Setting

Reboot System

SUBMIT

SUBMIT

Login Configuration

Player ID

Player Password

viewer

njvKq5H

Main
Video (1) | Video (2) | System

Source Naming

Src01 Name

Src02 Name

Src03 Name

Src04 Name

Src05 Name

Src06 Name

Src07 Name

Src08 Name

Src09 Name

Src10 Name

Still Name

SUBMIT

CVBS1

CVBS2

YC1

YC2

RGBS

DSUB

DVI1

DVI2

SDI1

SDI2

Still

Network Configuration

MAC address

IP address

Subnet mask

Gateway address

DHCP

SUBMIT

40:4c:54:00:00:55

192.168.10.55

255.255.254.0

192.168.11.1

0

Login Configuration

User ID

User password

Confirm password

SUBMIT

otkm

\*\*\*\*\*

Main
Video (1) | Video (2) | Stream | System

Source Naming

Src01 Name

Src02 Name

Src03 Name

Src04 Name

Src05 Name

Src06 Name

Src07 Name

Src08 Name

Src09 Name

Src10 Name

Src11 Name

SUBMIT

CVBS1

CVBS2

SV1

SV2

DSUB

RGB

DVI1

DVI2

SDI1

SDI2

Still

Network Configuration

MAC address

IP address

Subnet mask

Gateway address

SUBMIT

40:4c:54:00:00:66

192.168.10.23

255.255.254.0

192.168.11.1

Login Configuration

User ID

User password


Confirm password

SUBMIT

user9

\*\*\*\*\*

## ControlOR Player



Quicktime Player Open VLC Player Open

3. System login user change for [control web-page](#) and remote
  - Up to 5 users can be registered.
  - From [control web-page](#)  
After log-in control web-page, user name and password can be changed in Configuration-> System
  - From the remote  
In terminal window(RS232, IP) or SDS(RS232),  
'username' and 'userpass' commands change ID and pass.
4. Dynamic stream login ID and password
  - \*\* They are fixed at user1/user1 for the moment.  
(I thought I informed David about this. Maybe I am wrong.)  
They can be set using 'strm\_xxxx' commands from July 16<sup>th</sup> F/W updates.
  - From [control web-page](#)  
After log-in control web-page, user name and password can be identified in Configuration-> System. It is dynamic.